

H Type guide units

Load calculations

For offset dynamic loads or for long stroke applications (above the dotted line in the graph below, if possible use a guide with recirculating ball bearings. If not, divide the maximum load by 4. (Details of guides with ball bearings will be supplied on request)

